


CABINET PARTS
For Models: ABB2221FEW1, ABB2221FEB1
(White) (Black)

IIIus No.	. Part No.	DESCRIPTION
1	W10137539 W10123457 W10169671	Literature Parts Use & Care Guide Energy Guide Tech Sheet
2		Cabinet (Not a Servicable Part)
3	67001130 67001131 B5759649	Plug, Button (3) White Black Gasket
5 6 7	67006118 67003868 67006744	Roller Assembly Foot, Brake Pin, Center Hinge
9	67006611 67006521	Bolt, Adjusting (Front Roller) Screw
10	67001014 67001012	Black
11 12 13	67005822 67006473 67005064	
14 15	67006303 67006960	Screw Hinge, Center White
16 17	67007043 12566604ED	Black Hinge, Top Cover, Corner
18 19 20 21 22	67003484 67003485 67001067 67001069 67006564 67006101	White Black Clip, Drain Hinge Bottom Screw Cover, Unit Grille Assembly
23 24 25 26 27 29 30 31 32 33	67002223 67002224 67001098 67001066 67006425 67003796 67001097 12479901 67006662 M0274057 67007018	(Includes Clips) White Black Cover, FI Tb Tube, Drain Screw (9) Fiber, Acoustic Cover, Water Valve Plate, Cover Screw Shim, Non Metal Pin, Bottom Hinge Cover, LWR Hinge
34	12561901W 12561901B 12627302	White Black Clip, Grille

Following Parts Not Illustrated

8170942 Clamp, Tube

FREEZER LINER PARTS
For Models: ABB2221FEW1, ABB2221FEB1
(White) (Black)




FREEZER LINER PARTS
For Models: ABB2221FEW1, ABB2221FEB1
(White) (Black)

Illus No.	. Part No.	DESCRIPTION
1		Linar (Not A
ı		Liner (Not A Seviceable Part)
2	67001291	Gasket, Foam
2 3	67001231	Panel Fz
J	07001040	Control
4	67001285	Cover, Light
5	67001046	
6	Y12570701	Socket, Light
7	67003420	Knob, Fz
		Control
8	A0282812	Bulb, Light
9	67001035	Housing, Frz. Light
10	67005869	Cover, Evaporator
11	67006425	Screw (7)
12	67001286	Module, Freezer
_	W10167028	Clip, Evap. Motor
14	67005653	Switch, Light
15	67001776	Gasket, Bottom
16 17	13024802 W10167023	Cover, Fan Shroud
18	2169142	Shroud, Evap.Fan
10	2109142	Blade, Fan (Evaporator)
19	W10121318	Grommet
20	67003636	Motor, Evaporator
21	D7753903	Funnel, Drain
22	M0500703	•
23	B8381501	Gasket
Eol	lowing Po	rte Not Illustrated

Following Parts Not Illustrated

W10130480 Harness, Lights (Freezer)


FREEZER DOOR PARTS
For Models: ABB2221FEW1, ABB2221FEB1
(White) (Black)



Illus No.		DESCRIPTION	Illus No.		DESCRIPTION	Illus No.		DESCRIPTION
1		Freezer Door	3		Door Gasket,	6	10712401	Plug, Button (2) White
	W10168717	(w/ Insulation) White		W10130894	Magnetic White	,	W10153326	
	W10168719			W10130587		7	67003934	
2		Handle	4	07004400	Plug, Hole	8	07004077	Bushing
	67005140			67001130 67001131			67004977 67004978	
	67005125	Віаск	5	67001131	Stop, Door	9	67006831	
				67003779		1	67006287	()
				67003780	Black			

REFRIGERATOR LINER PARTS


For Models: ABB2221FEW1, ABB2221FEB1 (White) (Black)



Illus No.	. Part No.	DESCRIPTION	Illus No.	. Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1 2 3 4 5 6	67001040 67001034 67001036	Liner (Not A Serviceable Part) Module, Light Belt, Damper Tensioner, Belt Timer, Defrost Switch, Light	9 10 11 12 13	Y12570701 67002301 12990514	Ref Light Screw Cover, Damper	17 18 19	67003104	Knob, Damper Upfront Logo, Light Pan, Timer Light Housing
		Plug, Button White	15		Damper, Gear Assembly	Foll	owing Pa	arts Not Illustrated
8	67001035	Housing, Light	16	67001033	Knob, Gear		67001043	Harness, Controls (Refrigerator)

REFRIGERATOR DOOR PARTS

For Models: ABB2221FEW1, ABB2221FEB1 (White) (Black)




FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR DOOR PARTS
For Models: ABB2221FEW1, ABB2221FEB1
(White) (Black)

IIIus <u>No</u>		DESCRIPTION
1		Refrigerator Door
		(w/Liner)
	67001009	White
	67001008	Black
2	67006682	Screw
3	67003819	Door, Dairy
4 5	67001279 67001021	Tray, Dairy Bucket, Medium (4)
6	07001021	Plug, Handle Hole
U	67001130	White
	67001131	Black
7	0.000.	Plug, Button
	10712401	White
	67004838	
8		Door Gasket,
	144040000	Magnetic
	W10130893	White
9	W10131327	Black Door Handle
9	67003129	
	67003129	
10	12528501	Nameplate
11	67001280	Retainer, Ref Door
12	67006287	Screw
13		Bushing
	67004977	White
	67004978	Black
14	07000770	Stop, Door
	67003779 67003780	
15	M0274057	Shim, Non Metal
16	12248201	Screw
17	122 1020 1	Trim, Handle Btm
	67005134	
	67005135	Black
18		Trim, Top Handle
	67005131	White
40	67005132	
19	10423131	Bin, Utility

UNIT PARTS
For Models: ABB2221FEW1, ABB2221FEB1
(White) (Black)




UNIT PARTS
For Models: ABB2221FEW1, ABB2221FEB1
(White) (Black)

Illus No		DESCRIPTION	Illus		DESCRIPTION	Illus.	Part No	DESCRIPTION
No. 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19	67006433 W10162928 67005744 67006425 67005491 W10167036 W10119855 67004713 61004743 67001794 W10136415 W10136414 61003210 67003426 W10137529 67006573 67003493	Blade, Fan Basepan Screw Block, Condenser Tube, Discharge Harness, Evap. Heater Drain Pan Grommet (3) Evaporator Heater Clip, Capacitor Overload (Includes Relay) Gasket Thermostat Grommet Screw Grommet (4) Condenser	29 30	67001080 67006737 12001919 67001084 67001083 67004432 10428101 13060301 23178454 W10130129 2264017 67006434 W10153406 67004953 67004954 10547003 67005149	Evaporator Dam Right Side Left Side Motor, Fan Clip, Heater Harness, MC (Includes Power Cord) Drier (Service) Compressor Capacitor Axle, Roller Shroud Bracket, Fan Motor Screw Clip, Drier Roller Clip, Evap	and O	978025 978026 978027 978028 978029 978030 876764	(3/8")

SHELF PARTS


For Models: ABB2221FEW1, ABB2221FEB1 (White) (Black)



SHELF PARTS
For Models: ABB2221FEW1, ABB2221FEB1
(White) (Black)

Illus.	Part	
No.	No.	DESCRIPTION
1	67001057	Rail, Center Crisper
2 3	67004420 67005864	Trim, Crisper
4 5	67001075 12754804	Shelf, Freezer
6 7 8	67006626 67006360 10459928	Screw (12) Screw
9 10	67001314 10459927	Pan, Deli
11 12 13	67006400 10480412 67001054 67001053	Screw Shelf, Full Glide LH
14 15 16 17	D7725402 10370099 67002633 67001059	Tray, Ice Cube Glass, Shelf (2) Crisper (2)
18 19 20 21 22	67001056 67006878 67001073 67001317 10460108	Frame, Crisper Glass, Crisper Cover Ladder, Center Ladder, Side
23 24 25	10460107 10946008 10459806	` '

ICEMAKER PARTS
For Models: ABB2221FEW1, ABB2221FEB1
(White) (Black)



ICEMAKER PARTS
For Models: ABB2221FEW1, ABB2221FEB1
(White) (Black)

Illus No.		DESCRIPTION
1 2 3 4 5	2256086 67003729 67003932 489276 67003753	Bracket, Ice Maker Tube, Plastic Clamp Screw Valve–Inlet
6 7 8 9	67004028 67004710 A3223101 6282280	Arm-Shut Off Cover, Front Insert, Tube Mold & Heater Assembly (Also Order 542638)
10 11 12 13 14 15	628515 627843 2182124 2194712 2315522 627985	Cup Water fill Ejector Ice Stripper Support Retainer Thermostat Order 542369 Cement
16 17 18 19 20	8533917 489464 W10146389 M0114003 626678	Alumilastic) Screw Screw Harness, Ice Maker Clip, Speed Module Assembly (Includes Items 21& 22)
21 22 23 24 25	626684 489136 W10137519 67005603 67001255	Motor Screw Elbow, Fill Tube Funnel, Fill Tube Pan Ice
100	W10122519	Complete Ice Maker

OPTIONAL PARTS

For Models: ABB2221FEW1, ABB2221FEB1 (White) (Black)

Illus. Part No. No. DESCRIPTION	Illus. Part No. No. DESCRIPTION	Illus. Part No. No. DESCRIPTION	
PAINT, TOUCH-UP (1/2oz.)	PAINT, BULK (1 qt.)	TORX SCREW WRENCH	
72017 White 72032 Black	799344 White (Uncut) 799344 Black (Uncut)	1117510 Torx Key	
PAINT, PRESSURIZED SPRAY	Miscellaneous	ACCESSORIES	
(12 oz.)	212643 Sealer, Gum	2217192 Cleaner, Stainless Steel	
*350942 Primer, White *350930 White *350939 Black	(4 Feet) 479502 Tape, Vinyl (3/4 x 108") 505587 Sealer, Mastic (1 Qt.)		
*Important: The spray paint is not to be used where the paint may make contact with the door gaskets.	503695 Cork, Sealer (1/4 Pound) 542638 Grease, Silicone (1/2 Oz.) 542639 Cement, Alumilastic		
	(1–1/4 Oz.) 799833 Kit, Evaporator Repair (Aluminum Epoxy)		
	833938 Kit, Terminal Connector		